






Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /
Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /
Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /
Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb
/ Rendelhető alkatrészek / Запасні частини / Reservni delovi / Резервни делови /
Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daļu

XX = AA, AD...


Pos.	Part No.
1	A 963 131 NU
2	A 963 132 NU
3	A 963 146 NU
4	A 960 890 NU
5	A 960 891 NU
6	A 960 706 NU
7	A 963 443 NU
8	A 960 500 NU
9	A 960 893 XX
10	A 960 894 XX
11	A 960 895 NU
12	A 960 896 XX
13	A 960 897 XX
14	A 962 397 XX
15	A 960 704 NU
	A 962 476 NU
16	A 960 705 XX



MARA
A 9025 ..

Ideal Standard





1120 / A 866 106
Made in Germany



Ideal Standard International NV
Corporate Village - Gent Building
Da Vincilaan 2
1935 Zaventem
Belgium

www.idealstandardinternational.com





	P	bar		MAX. 10		5			Q
			0,5			1		(3 bar)	
	T	°C		MAX. 80		65		l/min	
						55		23	