







Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto
 Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat //
 Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /
 Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb
 / Rendelhető alkatrészek / Запасні частини / Reservni delovi / Резервни делови /
 Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daļu



Position

- 1 = A 962 068 AA
- 2 = A 963 667 NU
- 3 = A 963 751 NU
- 4 = A 961 485 AA
- 5 = A 961 667 NU (2x)
- 7 = A 963 372 NU
- 8 = A 962 715 NU
- 9 = A 962 985 NU
- 11 = A 962 058 NU
- A 960 196 NU
- 14 = A 960 001 NU
- 16 = A 963 395 NU (2x)
- 17 = A 963 685 NU




MELANGE
A 4266 ..









0116 / A 865 808
 (+ A 865 612)



Ideal Standard International NV
 Corporate Village - Gent Building
 Da Vincilaan 2
 1935 Zaventem
 Belgium

www.idealstandardinternational.com





	P bar	0,5		5		Q (3 bar) l/min 13
	T °C		MAX. 80	65		
				40		

